


TIRE TIPS

A proactive approach to tire maintenance can increase tire performance, prevent costly downtime and avoid out-of-service violations. According to Roadcheck, 19% of out-of-service violations last year were wheel and tire related.

PROTECT YOUR INVESTMENT:

REGULARLY INSPECT TIRES FOR DAMAGE

- Tires should be removed from service for several reasons, including treadwear, damage or improper inflation
- Tires being mounted and returned to service should be inflated in safety cages



KEEP YOUR TIRES PROPERLY INFLATED IN ORDER TO MAXIMIZE PERFORMANCE

- Underinflation can cause poor handling, fast and/or irregular wear, decreased fuel economy and permanent structural damage
- · Overinflation can reduce traction, braking ability and handling, as well as result in uneven wear and an uncomfortable ride
- Tires found 20% or more underinflated should be removed, demounted and inspected by a trained professional
- To find recommended tire inflation visit goodyeartrucktires.com or reference the plate inside the driver's side door

CHECK TIRE PRESSURE WHEN YOUR TIRES ARE COLD

- Pressure in a hot tire may be as much as 10 to 15 PSI higher (never bleed air from a hot tire)
- With every 10-degree increase/decrease in outside temperature, pressure changes by 2%
- Ideally, checks should be executed weekly before the truck leaves the lot

Visit one of our Goodyear commercial dealer locations for a tire inspection by a TIA-certified technician or contact them today to schedule a fleet inspection!

Visit goodyeartrucktires.com



Enter your location





Trusted Products

Full range of tires, technologies and retreads with options for every fleet.





Complete Tire Management

Unparalleled programs and tools to optimize tire assets and ROI.

Find your total solution at goodyeartrucktires.com.

*Fleet research study, Nov. 2015, Lieberman Research Worldwide. 590-fleet sample.

